

TYPICAL CONNECTION ON ONE OR MORE POLES

NOTES:

- PROVIDE BREAK-AWAY TRON FUSE HOLDER AND 10 AMP FUSE. FERRAZ-SHAWMUT FEB-11-11-BA OR APPROVED EQUAL. LOCATE INSIDE POLE @ BEHIND HANDHOLE COVER.
- 2. INSULATE HOT/NEUTRAL SPLICES AS FOLLOWS: COVER WITH 2-LAYERS RUBBER TAPE-FILLING VOIDS. APPLY 1-LAYER 1/2 LAPPED PVC TAPE. APPLY 1-LAYER FRICTION TAPE & COAT WITH AN ELECTRICAL INSULATING COATING (SKOTCHKOTE OR EQUAL).

| DRAWN BY _ | J.S. | COUNTY OF MADERA | DRAWING NO. |
|-------------|-----------|------------------------|-------------|
| DATE | 6/9/1997 | STREETLIGHT CONNECTION | |
| REVISED BY_ | J.S.C. | DIAGRAM | 51-22E |
| DATE _ | 3/23/2011 | | |